

Colored Wiring Diagram

Diagram shows single motor connection. Use duplicate terminals to connect a second motor.

Main Feed: Connect 120 or 240 VAC across terminals L1 & L2/N and configure motor for voltage used

Terminals T5 & T8 feed the Cap/Start winding, ML1 and ML2 are to motor run windings

