

# T# Wiring Diagram

Diagram shows single motor connection. Use duplicate terminals to connect a second motor.

**Main Feed:** Connect 120 or 240 VAC across terminals L1 & L2/N, and configure motor to voltage used

Terminals T5 & T8 feed the Cap/Start winding, ML1 and ML2 are to motor run windings

